



USER MANUAL

PLPak Version 1.01

**STRUCTURAL ANALYSIS SOFTWARE USING BOUNDARY
ELEMENTS METHOD**

PLPAK basic tutorials

Tutorial 14 – PLGen and PLView boundary conditions

CONTACT DETAILS:


www.be4e.com

support@be4e.com

Tutorial 14

The objective of this tutorial is to review the boundary conditions in the PLGen and the PLView.

I – In PLGen draw a slab with four columns.



II – Under Segment mode select the edge of the slab and right-click. The shown box appears change it to clamped.



III – Open the model in PLView by clicking on BE Model. In PLView enable BCs and the BC legend. Notice that the boundary conditions are identified accordingly.

